



WOOD REVIVER POWER GEL

Cleans and refreshes greyed wood highly effectively!



Clear

PRODUCT DESCRIPTION

Jelly-like special cleaner for refreshing greyed exterior wood. Wood Reviver Power Gel is a non-drip product, and thus it is easy to apply – especially on vertical surfaces. The gel penetrates the wood deeply and removes grey patina. Afterwards by re-applying oils, the fresh warm colour tone of the wood is restored.

RECOMMENDED USE

Osmo Wood Reviver Power Gel is highly recommended for wooden decking, timber cladding, garden furniture and similar surfaces.

INGREDIENTS

Osmo Wood Reviver Power Gel contains biodegradable oxalic acid (<5 %). This product is free of solvents, formaldehyde, chlorine compounds and amines. Detailed declaration of ingredients available upon request.

TECHNICAL DATA

Specific gravity: 0.99-1.05 g/cm³

Viscosity: >70s DIN EN ISO 2431/3 mm, thixotropic

Odour: faint/mild, after drying odourless

Flash point: not applicable

STORAGE

Up to 2 years and longer if container is kept dry, closed tightly and stored at temperatures between 5 and 35°C. Do not expose to frost during transport!

SURFACE PREPARATION

Remove coarse dirt from greyed wood; afterwards dampen with water.

Wood Reviver Power Gel is ready to use, do not thin. Perform a trial application before treating wood with Wood Reviver Power Gel.



METHODS OF APPLICATION

Apply the gel generously along the wood grain. After approx. 20 minutes clean with a hard brush and rinse with a lot of water. After approx. 48 hours drying time, protect the now newly refreshed wood with a wood finish (e.g. Osmo Natural Oil Woodstain, Decking-Oils, Country Colour).

For mechanical processing on decking, we recommend using Osmo Decking and Flooring Cleaner.

CLEANING OF TOOLS

Immediately after use, with soap and water.

DRYING TIME

Approx. 24-48 hours (normal climatic conditions, 23 °C/50 % rel. humidity). Lower temperatures and/or higher air humidity can increase the drying time. Allow for good ventilation while drying.

COVERAGE

1 litre covers approx. 10 m² with one coat.

Product coverage depends significantly on the character of the wood. All information refers to smooth and planed/cut surfaces. Other surfaces may lead to reduced coverage.

NOTE

Protect metal (e.g. hinges) and plants against direct contract (e.g. cover ornamental and farm plants with a tarpaulin.)





CAUTION

Keep out of reach of children. Do not get in eyes, on skin, or on clothing. If medical advice is needed, have product container or label at hand. Observe the general safety regulations when handling chemicals. Safety data sheet upon request.

DISPOSAL

Dispose of leftover product and completely emptied packaging according to local official guidelines (waste code number 08 01 11). Only completely emptied cans can be recycled.

COLOUR TONES 6609 Clear

CAN SIZES 0.5 L; 2.50 L

The above mentioned information is provided to the best of our knowledge however without any liability.

Version 06/15





TEAK-OIL SPRAY

Easy to use and high coverage - penetrates deeply into wood!









PRODUCT DESCRIPTION

Clear, water and dirt-repelling oil to protect and maintain garden furniture and decking. Osmo Teak-Oil Spray penetrates deeply into the wood surfaces, regulates thereby moisture and prevents swelling and shrinkage. The microporous oil coating does not crack, peel or flake. To refresh, simply reapply (No sanding – no sanding dust!).

RECOMMENDED USE

Osmo Teak-Oil Spray protects, maintains and improves the appearance of garden furniture made of Teak and other hardwoods – in covered exterior areas. It is also well suited to the clear finishing of garden furniture and similarly used surfaces.

INGREDIENTS

Based on natural plant oils (sunflower oil, soya oil, thistle oil and linseed oil), siccatives (drying agents) and water-repelling additives. Dearomatized white spirit (benzene-free).

Propellant: propane/butane

Detailed declaration of ingredients available upon re-

quest.

TECHNICAL DATA

Specific gravity: 0.85-0.9 g/cm³ Viscosity: not applicable Odour: characteristic

Flash point: not applicable, aerosol

STORAGE

Up to 2 years and longer if can is kept dry and closed tightly.

SURFACE PREPARATION

Wood surface must be clean, dry and frost-free (moisture content max. 20%). Osmo Teak-Oil Spray is ready to use. Shake spray can well and carry out trial spray. Clean old microporous stains thoroughly. Old paints and lacquers must be completely removed. As a general rule, wear a dust mask during sanding works. Hard wood containing natural wood ingredients needs

Hard wood containing natural wood ingredients needs to weather off (for approximately 4 weeks) or be cleaned with Osmo Brush Cleaner and Thinner (degreaser). The finished surface is, among other things, influenced by the wood's natural characteristics. Therefore, a trial application is always required, especially for unfamiliar surfaces.

METHODS OF APPLICATION

Spraying distance approx. 25 cm. Afterwards massage into wood with a brush.

While applying, cover and protect surrounding areas and parts which should not be treated against the spray mist.

Wipe away any excess product with a cloth.

Allow to dry for approx. 12 hours with good ventilation and apply 2nd coat.

When renovating, one coat applied is usually sufficient.

Clean spray nozzle after use.

CLEANING OF TOOLS

With Osmo Brush Cleaner (free of aromatic compounds).

DRYING TIME

Approx. 12 hours (normal climatic conditions, 23 °C/50 % rel. humidity). Lower temperatures and/or higher air humidity can increase the drying time. Allow for good ventilation while drying.





COVERAGE

1 litre covers approx. 5-10 m² with one coat. Product coverage depends significantly on the character of the wood. All information refers to smooth and planed/cut surfaces. Other surfaces may lead to reduced coverage.

NOTE

Osmo Teak-Oil Spray is clear and therefore it does not protect against UV rays from the sun (greying). If the original colour tone of freshly sawn wood should be kept (e.g. Bangkirai), we recommend a coat with Osmo Decking-Oils in a natural shade or Natural Oil Woodstain in the appropriate colour tone.

CAUTION

Pressurized container: protect from sunlight and do not expose to temperatures exceeding 50°C. Do not pierce or burn, even after use. Do not spray on a naked flame or any incandescent material. Keep away from sources of ignition - No smoking. Keep out of the reach of children.

Do not breathe fumes/aerosol. Avoid contact with skin and eyes. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. Wear suitable protective clothing, gloves and eye/face protection. If swallowed, seek medical advice immediately and show this container or label. Use only in well-ventilated areas. Warning: Wash out any used cloth impregnated with this product immediately after use or store in an airtight container (danger of self-ignition). Must not be applied on the same spraying stand as lacquers or lacquer corrosives that contain NC (nitrocellulose). Risk of self-ignition.

Please stick to the regulations of the BG Holz (BGI 740 for coating units) and the BGV D 25 of the insurance association and the technical leaflet.

Danger



DISPOSAL

Dispose of leftover product and completely emptied packaging according to local official guidelines (waste code number 08 01 11). Only completely emptied cans can be recycled.

COLOUR TONE 008 Clear

CAN SIZES 0.4 I

The above mentioned information is provided to the best of our knowledge however without any liability.

Version 06/15